



Measurement Canada



The PS-USB Series is a strong, robust, and accurate range of scales particularly suited to a wide variety of weighing application (trade approved). The aluminum cast base comes with adjustable feet and leveling bubble for precise weighing. The indicator bracket is detachable.

The easy-to-operate PS-USB indicator features a large LCD display and RS-232/USB ports that can transmit and receive using a demand type protocol (NCI). The triple power modes (battery, AC adapter and USB) enable portability or permanent installation.

The PS-USB offers all the functions and features needed to improve efficiency and increase productivity in most warehouse and shipping/receiving areas.



Accuracy

NTEP at 3000d (3500d for the 70 lb),
Class III



Capacity

30 lb x 0.01 lb / 15 kg x 0.005 kg
70 lb x 0.02 lb / 30 kg x 0.01 kg
150 lb x 0.05 lb / 60 kg x 0.02 kg



Power

9 VDC, 600mA adapter with center
positive (included) or four AA batteries (not
included) or USB (VCP) cable (included)



Display

6½ digits 1" / 25 mm high, seven
segments LCD with blue backlight. Cable
length 29.5" (75 cm)



Construction

Durable cast aluminum upper load cell
supporter and cast aluminum base with
removable stainless steel platter and
indicator bracket



Operator Keys

Hold/Setup, Print/Func, Acc/Total,
Unit/Data, Tare/Preset, On/Off/Zero

PS-USB Portable Shipping Scale

Specifications

Unit: lb, lb/oz, kg

SBI 240 Indicator: NTEP approved with detachable bracket and extendable cable up to 29/5" (75 cm)

Emulation Protocols: Standard NCI default with field configurable settings of NCI, 8213, 3835 and Autosend. Interfaces with software programs such as UPSTM Worldship Online.

RS-232/USB (VCP): Full duplex serial port (USB cable included)

Other Functions: Weighing, counting, check weighing, percent weighing, accumulation

Battery Life: 20 hours

Operating Temperature:

14° F to 104° F / -10° C to 40° C

Product Dimension (L x W x H):

16" x 14" x 3.15" / 411 mm x 355 mm x 80 mm

Platform Dimension (L x W):

14" x 12" / 355 mm x 305 mm

Product Weight: 10 lb / 5 kg

Packaging Dimension (L x W x H):

20" x 18" x 6"

505 mm x 465 mm x 150 mm

Shipping Weight: 14 lb / 6.3 kg

Certifications: NTEP CC# 15-084 / Measurement Canada AM-6006 (SBI-240), NTEP CC# 15-083 / Measurement Canada AM-5998 (PS-USB base), Base NSF listed



brecknellscales.com

brecknellscales.co.uk

— *Part of Avery Weigh-Tronix*